h2o audio®

TRI MULTI-SPORT

WATERPROOF OPEN EAR HEADPHONES

SWIM   BIKE   RUN

TABLE OF CONTENTS:

h2o audio

HOW TO CHARGE

Connect the 4 pin USB cable to the H2O Tri (It will attach only 1 way with the magnets).

- **BATTERY CHARGING:** Red LED
- **BATTERY FULL:** Blue LED
- **FULL BATTERY PLAY TIME:** ~8hr

When you turn ON the H2O TRI you will hear the current battery level status.

CHAPTER 2:

TURN ON/OFF:
Press and hold the middle button for 3 seconds.

M (MIDDLE/MODE BUTTON)

POWER ON/OFF: Hold (3 sec) to Power ON/OFF

PLAY/PAUSE: 1-Click to Play/Pause audio

MODE CHANGE (Memory <-> Bluetooth):
2-Click (Double Click)

RESET: Hold for 10 seconds to Reset. Make sure headphones are Off. After 10 seconds you will see the LED light blink 3 times.

SHUFFLE MODE:

3-click (triple click) to turn on/off
(Only in memory mode)

SIRI/VOICE ASSISTANT

Long Press **(Only in Bluetooth Mode)**

ANSWER INCOMING CALL

1-click **(Only in Bluetooth Mode)**

+/- BUTTONS

VOLUME UP/DOWN: 1-Click

SKIP SONG: Hold + or - to skip to next or previous track.

SKIP FOLDER: 2-click to advance to next/previous folder (only in memory play mode)

CHAPTER 4: DOWNLOADING MUSIC TO MEMORY

- Make sure the battery is changed. If battery is too low the USB connection may fail.

- Turn OFF the headphones.

- Then, connect the USB cable to the H2O TRI 4-pin connector and then to the computer USB port. DO NOT BUMP the headphones while it is connected.

- After connecting, wait for few moments to the computer to register the device.

- H2O TRI will appear as a memory drive or USB Memory device in the File Explorer (Windows) or Finder App (MAC).

  IMPORTANT NOTE: Subscription based music like Spotify, Apple Music, Pandora, etc. are copyright protected and can NOT be copied to the memory

- Find the music files on your computer. The H2O TRI can play .MP3, .WMA and .M4A (Apple iTunes) music.

- Select or Copy the music files and then copy/paste or 'drag & drop' the files to the H2O TRI.

- The file transfer will start. Do not disconnect until all files have been copied.

- To remove or delete files on the H2O TRI - simply select the files in the H2O TRI memory and Delete them or drag to Trash.

- To disconnect it from the Computer, click Eject the H2O TRI or simply disconnect it.

TROUBLESHOOT USB CONNECTION

If you are having trouble with the USB connection, disconnect the H2O TRI from the computer, power off H2O TRI and restart the computer. After your computer has done a full restart – try to connect again. You can also try a different USB port. Make sure your H2O TRI battery is charged. You can also reset the H2O TRI headphones. Turn Off the headphones and the hold the Mode button for 10 sec. You will see a 3 blinking of the LED light.

CHAPTER 5: MEMORY MODE (FOLDERS & SHUFFLE)

- The music can be organized into different folders.
- Skip to next or previous folder = 2-CLICK +/- button.
- Turn on Shuffle Mode: 3-click M button to turn on / off shuffle mode.

CHAPTER 6: BLUETOOTH CONNECTION & PAIRING

- Start with the H2O TRI headphones OFF.
- Power ON the headphones (press middle button for 2 sec). You will hear the start up prompts and battery level. The default start will be MEMORY MODE.
- Change the MODE to BLUETOOTH MODE by 2-click or double clicking the M button. You will then head – Bluetooth Mode.
- Go to the Bluetooth Settings in your phone or smart watch. Look for the H2O TRI name and select it. This will complete the pairing and you will hear "Connected" prompt. A blue blinking LED light will also indicate that the Bluetooth is connected.

PLEASE NOTE

Bluetooth connection has a range of approx. 10m/30ft. in air and 10cm/2 inches under water.
Bluetooth does not penetrate water (due to laws of physics)
PLEASE SEE SWIMMING WITH H2O TRI for more about Bluetooth Mode.

The **H2O TRI headphones** are **OPEN EAR** and use Bone Conduction. The Speakers are sitting **IN FRONT** of the ear vs in the ear, leaving your ear open for other surrounding sounds.

CHAPTER 8: BIKING & RUNNING WITH H2O TRI

When biking or running, you can use either the Bluetooth or the Memory Mode.

- The memory mode will play music from the internal memory without the need of any other devices. i.e. you can leave your phone home.

- The Bluetooth mode will receive audio from a device you are carrying. Make sure you have paired the headphones with the device.

SAFETY TIP

It is important to adjust the audio level so that you are able to hear ambient sounds from around you – cars, traffic, etc. The H2O TRI has an open ear design that will allow you to hear what's around you easier.

SWIMMING WITH H2O TRI

WHICH MODE SHOULD I USE?

When swimming, we recommend using the Memory Mode – as this will provide you the uninterrupted sound without the need of additional devices.

However, if you have a music enabled smart watch like the Apple Watch – you can use this as the source for your audio while swimming. However, you need to place the smart watch with in 2-3 inches from the headphones. Put the watch under your swim cap or use the H2O Audio Apple Watch Clip (sold separately). NOTE: The Bluetooth range under water is only few inches (due to laws of physics)

HOW TO WEAR DURING SWIMMING:

Use your swim goggle strap or swim cap over the headphones to better keep the headphones in place.

TIP

For best audio experience, we recommend using earplugs to reduce the ambient sound of water splashing.

SUPPORT & TROUBLESHOOT

TO RESET THE H2O TRI HEADPHONES:

Make sure the power is **OFF**, then press and **HOLD** the Power button for 12 seconds. This will reset the headphones.

ANY ISSUES?

Please do not hesitate to contact us at **SUPPORT@H2OAUDIO.COM**

Please note that your product has a **1 YEAR WARRANTY.**

H2OAUDIO.COM

FOR MORE TIPS AND VIDEOS

SCAN ME

H2OAUDIO.COM/PAGES/H2O-TRI-HEADPHONES